







WARNING

Before installation and commissioning, you must read the safety instructions and warnings carefully and all the warning labels attached to the equipment.



IMPORTANT

Failure to comply (even partially) with the instructions given in this manual will invalidate the product warranty and relieves the manufacturer of any responsibility



IMPORTANT

The alteration of machine operation, design or the replacement of parts not approved by the manufacturer may void warranties and approvals.



IMPORTANT

This machine is intended for commercial use only.

CONTENTS

| Safety Instructions | |
|--------------------------------------|----|
| Installation Installation Diagram | |
| Operating Procedures | |
| Troubleshooting | .8 |
| Schematic Diagram | .9 |
| Wiring Diagram1 | 10 |
| Accessories1 | 11 |

We have checked that the contents of this document correspond to the model described. There may be discrepancies nevertheless, and no guarantee can be given that they are completely identical. The information contained in this document is reviewed regularly and any necessary changes will be included in the next edition. We welcome suggestions for improvement.

Specifications and document subject to change without prior notice.

Information supplied in this manual is copyright. No part of this work may be reproduced or copied in any form or by any means, electronic or mechanical without the express permission of the author / publisher.

Service1 800 622 216Parts1 800 337 963



Distributed in Australia by Moffat Pty Limited 740 Springvale Road, Mulgrave, Victoria Tel 09 9518 3888 | Fax 03 9518 3818

Safety Instructions

WARNING



Equipment contains dangerous voltages and can be hazardous if installed or operated incorrectly. Non-compliance with warnings or failure to follow the instructions contained in this manual can result in loss of life, severe personal injury or serious damage to property.

Installation

- Use qualified, skilled personnel
- Follow installation instructions
- Connect to correct voltage and supply current
- Provide fully accessible electrical Isolation Switch & water supply valves

Training and Supervision

- · Read and understand the Operating instructions and train all staff
- This appliance must not be operated by children or infirm persons
- Machine panels must only be removed by suitably qualified and trained personnel – internal hazards include live electrics and very hot surfaces
- This appliance is not intended for use as a stepladder

Hot Surfaces

• Some surfaces may be hot or very hot

Chemicals

- Commercial dishwashing detergents are hazardous handle with care
- Read and follow the safety information found on the labels of detergent containers and Material Safety Data Sheets
- Use protective eyewear and clothing if decanting containers

Hot Water

- Do not put hands in wash water which may be over 60°C and contain hazardous caustic detergent
- Rinse water can be over 90°C
- Door safety switches are designed for emergency use only

Cleaning

- Do not hose down the machine or splash water over the exterior
- Watch for broken glass etc when cleaning the inside of the machine

Service/repair

- Under no circumstances the user should attempt to carry out repairs
- All service/repair work must be carried out by qualified personnel only

Power Cord Replacement

• If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard

Installation Checklist

WARNING

Installer must be suitably qualified and ensure compliance with all codes and standards including AS/NZS3500.1.

Unpack

• Unpack the machine, check for damage and complete delivery.

Positioning

- Place machine on sound waterproof self draining floor, fit feet and adjust feet to level
- Allow room for adjacent chemical containers

Water

- Flush supply lines before connection
- Connect hose supplied to adjacent accessible isolator valve 20 mm 3/4 male
- Flow rate required 20 litres per minute
- Temperature 65°C
- Consumption per cycle 1.5 litres
- Pressure required 200-350 kPa fit limiter above this pressure
- Back Flow Atmospheric Vacuum Breaker
- Potable water quality is required filter or soften if necessary

Water Quality Requirements

| Hardness | ness | | ppm | | рН | |
|-------------|------------|-------------|------------|-----------|-----------|-------------|
| min | | | 20 | | 7 | |
| max | | | 100 | | 8 | |
| lons | Cl- | SO ₄ | Fe | Mn | Cu | Cl ₂ |
| Max mg/L | 100 | 400 | 0.1 | 0.5 | 0.05 | 0.1 |

Power

• Machine shipped with cordset for 15 A 240V 50Hz via adjacent switched outlet

Waste

• Connect drain pump hose supplied to upstand or sink waste connection

Detergent

- Note that detergent is hazardous read instructions and handle with care
- Insert hose into container of commercial dishwasher low foam detergent
- Pump will prime as machine fills and then comes up to strength with use

Rinse Fluid


- Insert hose into adjacent container of commercial dishwasher rinse fluid
- Injector accessible via front panel increase consumption by winding adjusting screw out
- Every turn of the adjusting screw will increase the dose by about 0.4ml

Operation

• Run several cycles, ensure that operator has read and understands instructions

Troubleshooting Installation

• If machine doesn't fill after switching on power, check & ensure that hot water supply tap is open, water supply pressure is not below specification





XG Machine Operation



START UP

Turn machine on at wall. Fit filter, upstand and shut door. Press Power On button on machine. Power button light glows red and machine fills automatically Rinse temperature will begin to rise on the temperature gauge once the machine has filled.

OPERATION

Load rack into machine and shut door Press Start button to activate 1 minute cycle - start button glows green while machine operates. When Start button light goes out, cycle is complete. Remove rack, close door.

NOTE: Machine might operate longer than specified above if rinse water temperature is below required temperature.

SHUT DOWN EVERY NIGHT

Open door and press Drain button Drain button glows blue as machine drains. After draining starts remove drain upstand once the water level is below the top of the upstand. Allow to drain for approximately 1 minute or until wash tank is empty. Turn Drain and Power buttons off. Remove filter and rinse clean. Replace filter and drain upstand.

DAILY CLEANING

The machine must be drained and cleaned at the end of each day. Drain the machine as per the shut down instructions. Remove, clean and replace filters. Regularly check the wash and rinse jets on the wash and rinse arms and clean if necessary.

MAINTENANCE

Regular servicing of the dishwasher is essential for high performance, efficient operation and long machine life. Contact us for information on a maintenance program.

WASHTECHService1800 622 216Parts1800 337 963



Operating Procedures

PRE-RINSING

Pre-scraping of dishes is required by Food Hygiene Regulations. The best method is to pre-rinse with warm water with a Fisher Pre-rinse Unit - or alternatively by scraping or dunking in water. Cutlery should be pre-soaked in warm water, preferably containing a cutlery pre-soak compound - refer to your chemical supplier.

RACKING PROCEDURES

Do not overload racks or cutlery containers, minimise the overlap of crockery. Wash cutlery unsorted, handles down. Cycle times are short and water consumption per cycle low – so there is no advantage in overloading racks.

CYCLE TIMES

The XG has A 60 second cycle.

CHEMICAL


Correct type and quantity of detergent is essential for good results. Use good quality chemicals and regularly check containers. Discuss the use of drying agent and cutlery pre soak solution with your chemical supplier. Detergent concentration can be changed by adjusting the timer (refer service manual). Rinse Fluid is factory set to a low injection rate, and will take many cycles to prime. The operator can adjust this via the adjusting screw on the front cover (refer service manual).

DRYING

Single tank commercial dishwashers do not have a drying cycle. However, the machines do rinse at high temperatures which promotes fast drying particularly when drying agents are used. At the end of the cycle promptly remove the rack from the machine – leave the rack on the bench for 2 to 3 minutes before emptying.

REGULAR CLEANING – at least once a week

Remove wash and rinse arm by undoing central thumbscrew (1). Inspect all jets including top jet (2), use toothpick or paperclip and remove jets if necessary to flush and clear. Remove upstand (3) and filter (4). Clean and replace all items.





Distributed in Australia by Moffat Pty Limited 740 Springvale Road, Mulgrave 3170 Victoria Tel (03) 9518 3888 | Fax (03) 9518 3818 Web www.moffat.com.au

Troubleshooting


| Fault Filling | Cause | Remedy |
|---------------------------------------|-----------------------------------|---|
| Not filling | Water supply valve shut | Check Water supply valve |
| | Door Switch not operating | Check Door is closed |
| Filling during wash cycle | Upstand not fitted properly | Check Drain upstand is fitted |
| Heating | | |
| Dishes not hot enough | Machine not rinsing | Check water supply temperature |
| | Rinsing but not hot | Check water supply temperature & arms spinning freely |
| Cycle start | | |
| Does not start Cycle Finish | Door switch | Check door is closed |
| Wash too long | Water supply cold | Check water supply temperature |
| Performance | | |
| Poor wash result | Detergent not used | Use quality low foam product |
| | Overloading racks | Do not overload racks |
| | Not pre-rinsing | Use Fisher pre-rinse |
| | Wash arms not rotating | Remove and clean arms/check bushes |
| | Wash jets blocked | Remove arms and clean jets |
| | Excessive soiling | Pre-rinse/use long cycle |
| | Unrealistic expectation | E.g. baked on soiling requires pre-soaking |
| Poor rinse results | Rinse jets blocked | Remove arms and clean jets |
| | Rinse arms not turning | Remove arms, clean jets, check bushes |
| | Poor racking procedures | Do not overload racks |
| | Excessive wash tank soil build up | Pre-rinse, change wash water regularly |
| Not drying | Poor wash/rinse performance | Refer above |
| | Low temperatures | Check heating systems |
| | Drying agent not used | Use quality drying agent/rinse fluid |
| Foaming Wash | Excessive Rinse Fluid | Adjust Rinse Fluid Injector |

XG-3 Schematic Diagram 06018212/07/161A






XG-3 Wiring Diagram







K0401 GLASS RACK 365mm

600 90021 ASSY GA/GM LEG (INOX 32x180xM10)

7026@ BAG MINIGRIP 230 x 305 x 70mu



600 60080 2m HOSE ANGLE END Information supplied in this manual is copyright. No part of this work may be reproduced or copied in any form or by any means, electronic or mechanical without the express permission of the author/publisher

Distributed in Australia by Moffat Pty Limited

MOFFAT®

740 Springvale Road Mulgrave 3170 Victoria Australia

24HR Service 1800 622 216Parts1800 337 963

| Tel | 03 9518 3888 |
|--------|----------------------|
| Fax | 03 9518 3818 |
| E-mail | vsales@moffat.com.au |
| web | www.moffat.com.au |

ISO900⁻

All Washtech products are designed and manufactured by Washtech using the internationally recognised ISO9001 quality management system, covering design, manufacture and final inspection, ensuring consistent high quality at all times.

In line with policy to continually develop and improve its products, Washtech Ltd reserves the right to change specifications and design without prior notice.

an Ali Group Company







XG Economy Undercounter Glasswasher – 365mm Rack W 440mm x D 515mm x H 780mm

Washtech's XG is a compact recirculating glasswasher ideal for the tightest of locations. With one of the industry's lowest water consumption rates along with leading rinse heating, the XG provides excellent wash results in less time, while being light on operating costs and the environment.

The XG features Washtech Hybrid Controls which combine IP65 stainless switches, tried-and-tested switchgear, with a customisable electronic timer.

Since 1981 Washtech dishwashers and glasswashers have been constructed from heavy-duty stainless steel, and are engineered specifically for Australian conditions and regulations. Backed by the most extensive service network and spare parts inventory in the region, your Washtech glasswasher will not let you down.

Standard Features


- Quikstart1minute wash cycle
- Washes up to 540 glasses per hour
- Low hot water consumption of 1.5 litres per cycle
- Washtech Hybrid Controls
- Self cleaning cycle
- QuikConnect (Plug & Play) installation, supplied complete with:
 - Water supply hose
 - Detergent and rinse aid pumps with injector lines
 - Drain pump with outlet hose
 - 15 amp plugset
 - No commissioning required
- Heavy-duty stainless steel construction
- · Lower wash/rinse arm with precision moulded jets and an upper rinse jet
- Watermark approved backflow prevention
- Easy-clean composite wash filter
- Comprehensive 5-2-1 Warranty

Includes:

• 1 x K0401 - 365mm glass rack










Α

в

с



XG Economy Undercounter Glasswasher - 365mm Rack W 440mm x D 515mm x H 780mm



| Hot water Temperature Connection Pressure Flow Quality Backflow Prevention | 65°C 3/4" male; hose supplied 200-350kPa 20 litres per min Potable - refer table Atmospheric Vacuum Breaker | Dimensions Width Depth Height Weight Cubicmetres | Machine 440 515 780 29 | Packed 480 570 740 42 0.2 |
|--|--|--|---|---|
| Consumption | 1.5 litres per cycle* | Water Quality | Min | Max |
| Waste | | pH Hardness ppm | / 20 | 8 100 |
| Connection | Hose supplied for 38mm open standpipe 750 high | Cl- SO ₄ | 20 | 100 100 400 |
| | or connection to sink trap | Fe | | 0.1 |
| | | Mn | | 0.5 |
| Electrical | V Hz A/phase max.kW | Cu | | 0.05 |
| Single Phase | 240 50 15 3.15 | Cl ₂ | | 0.1 |

Refer operator manual for installation instructions. Isolating switch must be within 1m of, and not directly behind the machine. Isolating water valve must be readily accessible. *Consumption may vary with site conditions.

an Ali Group Company







Australia Moffat Pty Limited

Victoria/Tasmania

740 Springvale Road Mulgrave, Victoria 3170 Telephone 03-9518 3888 Facsimile 03-9158 3833 vsales@moffat.com.au

New South Wales

Telephone 02-8833 4111 nswsales@moffat.com.au

South Australia Telephone 03-9518 3888 vsales@moffat.com.au

Queensland

Telephone 07-3630 8600 qldsales@moffat.com.au

Western Australia

Telephone 08-9202 6820 wasales@moffat.com.au



ISO9001 All Washtech products are designed and manufactured by Washtech using the internationally recognised ISO9001 quality management system, covering design, manufacture and final inspection, ensuring consistent high quality at all times.

In line with policy to continually develop and improve its products, Washtech reserves the right to change specifications and design without notice.



© Copyright Moffat Ltd Version: 1806